




INSTALLATION INSTRUCTIONS SPOOL VALVE KIT


Power Survivor 40





chapter "Seal Replacement" in the manual.











press the spool valve completely into the borehole.

