

# INSTALLATION INSTRUCTIONS CLEANING VALVE

Power Survivor 40

## **PURPOSE OF THE KIT**

The kit provides a new cleaning valve assembly for the PowerSurvivor 40.

## KIT CONTENT

- Cleaning valve assembly
- O-rings
- Cap screws

### **TOOLS REQUIRED**

5/32" Allen wrench

#### DISASSEMBLY

Unscrew the two socket head cap screws using a 5/32" Allen wrench. Then remove the assembly from the pump body.

### **ASSEMBLY**

Print No.: 8012676/0

Lubricate the two O-rings included in the kit with silicone lubricant. Do not use petroleum-based lubricants. Install the larger O-ring under the cleaning valve assembly. Place the smaller O-ring in the recess on the pump body. Place the new cleaning valve assembly as shown in the illustration below. Secure the cleaning valve assembly with the two cap screws provided.

When operation is commenced again, carefully inspect the watermaker for proper operation and any leaks or other signs of incorrect assembly.

