
TROUBLESHOOTING


SYMPTOM	CAUSE	REMEDY
Motor/Piston Not Moving	Cables not plugged in properly	Unplug all cable connections, then plug back in. Check cable ferrules are properly inserted into DC/DC converter.
	Solar not providing enough power	Orient solar panels perpendicular to sun rays or switch to another power supply
No water rejected or produced	Intake out of water	Place pre-filter back in water or change location of adjustable hose weight
	Intake filter blocked/too dirty	Unscrew old intake filter and screw on provided second filter or clean by spraying water
No freshwater	Pressure relief valve not sealed	Close pressure relief valve
	Air bubble in watermaker	While running, tilt the watermaker to the left 30° then to the right 30°. Repeat 4 times.
Salty product water	System needs time to stabilize	Sample water regularly for up to 45 minutes
	Handheld test read inaccurately	Ensure ×10 is not seen in corner of window

QUICKSTART GUIDE










2. CONNECT TO POWER:



3. STARTUP PROCEDURE:

